tempmate.°-GS2

OPERATION INSTRUCTIONS

START LOGGER

Continuously press the green Start button for more than 5 sec.

The screen starts flashing the word "START", indicating the logger start. At this time, the icon r is displayed on the left side of the screen, indicating that the logger has been started successfully.

STOP LOGGER

Continuously press the red Stop buttor for more than 5 sec.

When the screen starts flashing the symbol $\ensuremath{\textbf{BBBBB}}$, Please release the button and the logger stops.

Optionally, the logger can be configured for stop from the cloud platform remotely or by connecting to the USB port.

DISPLAY INDICATION

- \checkmark The temperature is normal.
- X The threshold has been exceeded.
- **HI** The high threshold has been exceeded.
- LO The low threshold has been exceeded.

